

# Sharpat Pro Kit

Patent Pending

**Our goal is to provide a better product to streamline your student evaluations.**

**Thank you for your efforts!**

## Sharpat Pro Kit Assembly Instructions:

1. Remove kit Lid (B) (not shown) by undoing hinged snaps.
2. Insert four ½” pads into imprints on the bottom of Sharpat Kit receiver box (A) to prevent sliding.
3. Place stem (C) into center receptacle. *(Note Keying)*
4. Insert Stem (C) into larger end of Extension (D).
5. Slide Adapter Base (E) over smaller end of Extension (E).
6. Using screw (J) secure adapter onto notched fins of Extension (E) to height desired.
7. Install screw (I) for camera leveling adjustments.
8. Use screw (J) to clamp or tri-pod mount web camera to be used.
9. Press camera cable into pinch slots on camera adapter (E) then use twist-tie to secure cable to base of Stem (C).
10. If purchased, install Anti-Glare Kit (optional) at this time. (Refer to Anti-Glare Option installation instructions)
11. Connect USB camera to computer. Using desired application program and adjust camera if target is out of focus.
12. For disassembly reverse steps 2-11.


### Tips for using the Sharpat Pro Kit:

- Ensure desired camera view is displayed.
- Select correct image orientation when scanning bubble tests
- Maximize the scan test box in viewing window.
- Make sure you are using an appropriate web-browser. Google Chrome and Mozilla Firefox, or Safari are recommended.
- To alleviate skewing of documents/tests when using automatic positioning, set partitions in desired partition slots.
- For maximum control of lighting environment we suggest using the Sharpat kit Anti-Glare Option (AGO)
- When assembled the kit is effectively one unit and can be relocated without requiring camera re-adjustment
- Extension (D) may be rotated on Stem (C) for documents larger than 9.0” x 11.5”.
- Your kit is extremely versatile and may be used for bubble test scanning, for video-conferencing, as a document camera, etc.
- YAWCAM is a favorite of ours for document camera usage.
- For more information please see our website [www.sharpatkits.com](http://www.sharpatkits.com) or email us at [support@sharpatkits.com](mailto:support@sharpatkits.com) or [sales@sharpatkits.com](mailto:sales@sharpatkits.com).

**\* Part of the Anti-Glare Option (AGO). Option ordered separately.**

Parts List – Not including camera				Camera Clamp (G)	P1-008	Target Decal (K)	P1-012
Receiver Box (A)	P1-001	Adjustable Extension (D)	P1-005	Football-shaped screw (H)	P1-009	Cabling Clip - <i>(not shown)</i>	P1-013
Lid (B)	P1-002	Adapter Base (E)	P1-006	Wheel-shaped screw (I)	P1-010	Partitions – <i>(not shown)</i>	P1-014
Adjustable Stem (C)	P1-003	Adapter Pivot (F)	P1-007	Thumb-tab screw (J)	P1-011	½” Pads – <i>(not shown)</i>	P1-015

	▪ (H) Football shaped screw - Used to secure adapter to stem.
	▪ (I) Wheel-shaped screw – Used to level camera platform.
	▪ (J) Thumb-tab screw - Used for tri-pod mount or for camera clamp.



Tel: (714) 273-2265  
 Email: [support@sharpatkits.com](mailto:support@sharpatkits.com)  
 Fax (866) TEST KEY / (866) 837-8539

Please visit our website for warranty information, helpful hints, and more.

Web: [www.sharpatkits.com](http://www.sharpatkits.com)  
 Sharpat Kits, Inc.