


Sharpat Pro Kit Assembly Instructions:

1. If desired there are four ½” pads to insert into imprints on the bottom of Sharpat Kit receiver box (A) to prevent sliding.
2. Place telescoping stem (C) into center receptacle.
Note Keying slots.
3. Use screw (J) to secure adapter on telescoping stem (C).
Install screw (K) for camera leveling adjustments.
4. Use screw (L) to clamp or tri-pod mount web camera to be used.
5. Press camera cable into pinch slots on top of adapter (F) and use the twist-tie to secure cable to base of telescoping stem (C).
6. If utilized, place the light tent stems (D) into corner receptacles.
7. Attach stem extensions (E) into receptacles on bottom of lid (B).
Note: Make sure extensions are securely in place.
8. Place stem extensions (E) onto top of light tent stems (D).
9. If need be, drape Anti-Glare Cover over assembled kit.
10. Connect USB camera to computer. Using desired application program adjust camera as needed.
11. For disassembly reverse steps 2-10.

Tips for using the Sharpat Pro Kit:

- Make sure selected camera is displayed in the viewing area.
- When scanning bubble tests ensure correct image orientation and maximize the test box in viewing window.
- Make sure you are using appropriate web-browser. Google Chrome and Mozilla Firefox, or Safari are recommended.
- Utilize partitions and desired partition slots for best fit of documents to prevent skewing of image when placed into box.
- For maximum control of lighting environment always use the Sharpat Kit Anti-Glare Option (AGO)
- When assembled the kit is effectively one unit and can be relocated without requiring camera re-adjustment
- Telescoping stem may be swiveled to utilizing alternate holes when using documents larger than 9.0” x 11.5”.
- Your kit is extremely versatile and may be used in various ways including but not limited to video-conferencing, as a document camera, etc. YAWCAM is a favorite of ours.
- For more information please see our website www.sharpatkits.com or email us at support@sharpatkits.com or sales@sharpatkits.com.



Parts List:

Kit Box (A)	P1-001	Stem Extensions (E)	P1-005	Football-shaped screw (J)	P1-009	Cabling Clip- (not shown)	P1-013
Kit Lid (B)	P1-002	Adapter Base (F)	P1-006	Wheel-shaped screw (K)	P1-010	Partitions – (not shown)	P1-014
Telescoping Stem (C)	P1-003	Adapter Pivot (G)	P1-007	Thumb-tab screw (L)	P1-011	½” Pads – (not shown)	P1-015
Light Tent Stems (D)	P1-004	Camera Clamp (H)	P1-008	Target Decal (M)	P1-012		